




The HeatmiserNeo Driver



The HeatmiserNeo driver connects to the Heatmiser Neo heating and hot water control system. Available for Commander and ObSys.

This document relates to HeatmiserNeo driver version 1.0 and 1.1

Please read the *Commander Manual* or *ObSys Manual* alongside this document, available from www.northbt.com

Contents


| | |
|---|----|
| Compatibility with the Heatmiser Neo System | 3 |
| Equipment | 3 |
| Values..... | 3 |
| Prerequisites..... | 4 |
| Using the Driver | 5 |
| Starting the Interface | 5 |
| Setting up the Driver..... | 5 |
| Checking Communications | 5 |
| Object Specifications..... | 6 |
| Example Object Reference | 6 |
| Device Top-Level Objects | 6 |
| Heatmiser Driver Setup | 7 |
| Find neoHub | 8 |
| Heatmiser Advanced Setup..... | 9 |
| Heatmiser System..... | 10 |
| System..... | 11 |
| Thermostat | 12 |
| Time Clock | 15 |
| neoPlug..... | 17 |
| All Zones..... | 18 |
| All Thermostats..... | 19 |
| All Time Clocks..... | 21 |
| Driver Versions | 22 |

Compatibility with the Heatmiser Neo System

The HeatmiserNeo driver allows North to interface with the Heatmiser Neo underfloor heating and hot water control system.

The driver connects, via an Ethernet network, to a single Heatmiser neoHub (Fig. 1). The neoHub supports up to 32 zone devices, including thermostats, time clocks and accessories.

The neoHub zones are polled by the driver for their values. These values are stored and made available as objects.



Equipment

Heatmiser devices compatible with the driver include:

- neoHub gateway
- neoStat thermostats and timeclocks
- neoAir battery-powered thermostats
- neoPlug power sockets

Values

Depending on the type of thermostat or timeclock devices connected, each zone typically has the following values available:

- Standby/Frost protect
- Room temperature
- Room humidity
- Floor temperature
- Temperature setpoint
- Output state
- Preheat optimum start
- Comfort level profiles
- Time clock times
- PIN lock
- Hold
- Holiday mode
- Output delay
- Program mode
- Temperature format
- Date & time

The HeatmiserNeo system does not generate alarm event messages.

Prerequisites

Use the Heatmiser Neo app on a mobile device to set up the neoHub and zones.

The neoHub is assigned an IP address from the local network's DHCP server; a static IP address cannot be assigned. If possible, we recommend creating a reservation for the neoHub within the router/DHCP server. If you are unable to find the IP address of the neoHub from the DHCP server, use the [Find neoHub](#) feature in the driver to scan the IP network.

Be cautious of adjusting values too frequently. The Heatmiser system uses a Zigbee wireless network with limited bandwidth, sending too many adjustments may cause requests to build up in the neoHub and the system to slow. Use the Write Messages Sent (A.WC) object to monitor how frequently adjustments are made.

The neoHub may become slow to respond – typically if there are problems with its wireless network, or values are adjusted too frequently. Use the neoHub Responding Slowly (A.NS) and Message Reply Time (A.RT) objects to monitor for this issue. If the driver fails to get a response from the neoHub in a timely manner, then it will disconnect and stop making requests for two minutes, allowing the Heatmiser system time to recover.

If you are connecting to a neoHub via a firewall, then the driver will require access to TCP port 4242 on the Heatmiser neoHub.

On the Commander platform, version 2.0 build 01/07/16 or later is required.

Using the Driver

On ObSys, the HeatmiserNeo driver is pre-installed. On Commander, the driver is available to download in the file 'Bank11 HeatmiserNeo.cdm'. On all of these North devices, you can use the driver to create an interface to Heatmiser. Once started, you will need to set up the driver before it can communicate with the Heatmiser Neo system.

Starting the Interface

- 📖 To start an interface using the HeatmiserNeo driver, follow these steps:
 - **Start Engineering** your North device using ObSys
 - Navigate to **Configuration, Interfaces**, and set a unused **Interface** to 'HeatmiserNeo' to start the particular interface
 - Navigate to the top-level of your North device, then rescan it

The driver setup object (Mc), labelled **Heatmiser Setup**, should now be available. If this object is not available, check an interface licence is available and the driver is installed.

Setting up the Driver

- 📖 To set up the driver, follow these steps:
 - Navigate to the **Heatmiser Setup** object (Mc). For example, if you started interface 1 with the driver earlier, then the object reference will be 'M1'
 - Set the **Host name/IP address** object (IA) to the IP address or host name of the neoHub.

Checking Communications

You can check that the interface is communicating by reading the **Device Communicating** object (DS). A value of 'yes' indicates the driver has connected to, and is communicating with, the neoHub.

Object Specifications

Once an interface is started, one or more extra objects become available within the top-level object of the device. As with all North objects, each of these extra objects may contain sub-objects, (and each of these may contain sub-objects, and so on) - the whole object structure being a multi-layer hierarchy. It is possible to navigate around the objects using the ObSys Engineering Software.

Each object is specified below, along with its sub-objects.

Example Object Reference

An example of a reference to an object in the same device: the Heatmiser System (S1) contains Heatmiser zone one (Z1). This zone contains a Standby state(V46). Therefore, the complete object reference is 'S1.Z1.V46'.

An example of a reference to an object in a different device: the IP network object (IP) contains Default Commander object (CDIP), which contains the object above (S1.Z1.V46) – therefore the complete object reference is 'IP.CDIP.S1.Z1.V46'.

Device Top-Level Objects

When an interface is started using the HeatmiserNeo driver, the objects below become available within the top-level object of the device. For example, if interface 1 is started, then the object references 'M1' and 'S1' become available.

| Description | Reference | Type |
|---|-----------|--|
| Heatmiser Setup Set up the HeatmiserNeo driver, started on interface <i>c</i> (<i>c</i> is the interface number) | Mc | Fixed Container: On the Commander platform this will be <i>[CDM v20\HeatmiserNeo v11]</i> On the ObSys platform this will be <i>[OSM v20\HeatmiserNeo v11]</i> |
| Heatmiser System Access Heatmiser system connected to interface <i>c</i> (<i>c</i> is the interface number) | Sc | Fixed Container: <i>[HeatmiserNeo v11]</i> |

Heatmiser Driver Setup

Object Type: *[OSM v20\HeatmiserNeo v11]*

Object Type: *[CDM v20\HeatmiserNeo v11]*

Object Type: *[OSM v20\HeatmiserNeo v10]*

Object Type: *[CDM v20\HeatmiserNeo v10]*

The HeatmiserNeo driver contains the following objects:

| Description | Reference | Type |
|---|-----------|--|
| Device Label Label displayed when scanning the system | DL | Obj\Text: max. 20 chars; Adjustable |
| Host name/IP address The host name or IP address of the neoHub. If specifying a host name include the full domain name, eg 'Neo-hub.yourdomain.com' | IA | Obj\Text: max. 63 chars; Adjustable |
| Find neoHub If you are unable to find the IP address of your neoHub, use this object to scan IP addresses on the local network | F | Fixed container: On the Commander platform this will be <i>[CDM v20\HeatmiserNeo v11\Find]</i> On the ObSys platform this will be <i>[OSM v20\HeatmiserNeo v11\Find]</i> |
| Device Communicating Indicates the driver has connected to and is communicating with the neoHub | DS | Obj\NoYes |
| Default Hold Time (mins) Default time to use when setting Hold Temperature or Timer Boost Time | HT | Obj\Num; Adjustable |
| Last Write Response Response message from neoHub after last set command | LR | Obj\Text |
| Advanced Setup Additional configuration options for the driver operation | A | Fixed container: On the Commander platform this will be <i>[CDM v20\HeatmiserNeo v11\Advanced]</i> On the ObSys platform this will be <i>[OSM v20\HeatmiserNeo v11\Advanced]</i> |

Find neoHub

Object Type: [OSM v20\HeatmiserNeo v11\Find]

Object Type: [CDM v20\HeatmiserNeo v11\Find]

Object Type: [OSM v20\HeatmiserNeo v10\Find]

Object Type: [CDM v20\HeatmiserNeo v10\Find]

The Find neoHub object triggers the driver to start searching the local network for a neoHub. A DHCP server must assign the IP address of the neoHub, and if a local DNS server is available, the neoHub can be accessed using the host name 'Neo-hub.yourdomain.com'.

If a local DNS server is not available, and the DHCP server's IP address leases are not accessible, then the driver can find the neoHub on the network. The driver attempts each IP address on the local subnet in turn, which can take a while.

Optional start and end IP addresses may be specified to limit the range of the search. If they are not specified, then IP address range of the North device is used.

The Auto Find object (A) is also available to re-find the neoHub if its IP address changes.

The State object (S) provides a description of which IP address the driver is currently attempting.

| Description | Reference | Type |
|---|-----------|-----------------------|
| Find Now Set the driver to start searching for a neoHub on the local IP network | N | Obj\NoYes; Adjustable |
| Auto Find Automatically attempt to find the neoHub again if communications are lost | A | Obj\NoYes; Adjustable |
| Start IP address Optional. First IP address to check for the neoHub. If not specified, then the first IP on the local subnet will be used, eg '192.168.1.1'. | IS | Obj\IP; Adjustable |
| End IP Address Optional. Last IP address to check for the neoHub. If not specified, then the last IP on the local subnet will be used, eg '192.168.1.254'. | IE | Obj\IP; Adjustable |
| State Description of current find action | S | Obj\Text |

Heatmiser Advanced Setup

Object Type: [OSM v20\HeatmiserNeo v11\Advanced]

Object Type: [CDM v20\HeatmiserNeo v11\Advanced]

The HeatmiserNeo driver advanced setup contains the following objects.

| Description | Reference | Type |
|--|-----------|--|
| Reset Driver This will clear the driver's database of values and then re-initialize communications with the neoHub | RST | Obj\NoYes; Adjustable |
| Value Read Update Time (s) The driver polls the neoHub periodically, storing all values in its database. The driver waits for this time period before polling for values again | UT | Obj\Num: 15...1200; Adjustable Default: 65s |
| Responding Slowly Indicates that the neoHub is taking longer than usual to respond (more than 20 seconds). This could indicate a configuration problem with the neoHub wireless network. | NS | Obj\NoYes |
| Response Time (s) The driver makes several different requests to read all values from the neoHub. This value reports the longest time taken for a reply | RT | Obj\Num |
| Value Writes Sent (per min) Indicates how many value adjustments the driver has sent to the neoHub in the last minute. Adjusting values too frequently can cause problems with the Heatmiser system. | WC | Obj\Num |
| Debug Enable This will store additional debug information in the record file. Use this option only when instructed by North Support | DE | Obj\NoYes; Adjustable |

Heatmiser System

Object Type: *[HeatmiserNeo v11]*

Object Type: *[HeatmiserNeo v10]*

The Heatmiser Neo system contains up to 32 zone devices, connected wirelessly to a neoHub. Objects are available to read and set values within each zone (Zx) and the system (S). Objects are also available to set values in all zones (AZ), all thermostats (AS), and all time clocks (AT).

| Description | Reference | Type |
|--|-----------|---|
| System System-wide settings held by the neoHub | S | Fixed container: <i>[HeatmiserNeo v11/System]</i> |
| Zone Label The Heatmiser zone number, <i>x</i> , is in the range 1...99. However, a maximum of 32 zones are supported. | Zx | Fixed container depending on device type. neoStat devices configured as thermostat: <i>[HeatmiserNeo v11/Thermostat]</i> neoStat devices configured as timeclock: <i>[HeatmiserNeo v11/Timeclock]</i> neoPlug devices: <i>[HeatmiserNeo v11/Switch]</i> Unknown device: <i>[HeatmiserNeo v11/Unknown]</i> |
| All Zones Set values in all devices | AZ | Fixed container: <i>[HeatmiserNeo v11/AllZone]</i> |
| All Thermostats Set values in all neoStat thermostat devices | AS | Fixed container: <i>[HeatmiserNeo v11/AllThermostat]</i> |
| All Timeclocks Set values in all neoStat timeclock devices | AT | Fixed container: <i>[HeatmiserNeo v11/AllTimeclock]</i> |

System

Object Type: [HeatmiserNeo v11/System]

Object Type: [HeatmiserNeo v10/System]

The System object contains system-wide configuration settings held by the neoHub.

| Description | Reference | Type |
|---|-----------|---|
| Device ID Available in driver v1.1 only | V166 | Obj\Text |
| Date & Time | TIME | Obj\DateTime; Adjustable |
| Time Zone Offset | V162 | Obj\Float: -12...14; Adjustable |
| Auto Daylight Savings | V153 | Obj\OffOn; Adjustable |
| Daylight Savings | V154 | Obj\NoYes |
| Network Time | V164 | Obj\OffOn |
| Network Time State | V158 | Obj\Text |
| Temperature Format | V151 | Obj\Text; Adjustable Values: 'C' or 'F' |
| Heating Levels Available in driver v1.1 only | V167 | Obj\Num |
| Away Available in driver v1.1 only | V165 | Obj\NoYes |
| Firmware Version | V155 | Obj\Num |
| Partition Count | V159 | Obj\Num |
| Program Mode Select the program mode option for the neoStats Comfort Level and Timeclock profiles. In 'Non-programmable' mode no profile is available. In '24 Hour' programming all days use Monday for the same profile. In '5Day/2Day' programming use Monday for the weekday profile, and Sunday for the weekend profile. In '7 Day' programming each day of the week has a profile. | V160 | Obj\Enum; Adjustable Values: 0=Non-programmable, 1=24 Hour, 2=5Day/2Day, 4=7 Day |
| Zigbee Channel | V163 | Obj\Num; Adjustable Values: 11, 14, 15, 19, 20, 24 or 25 |
| Homekit Available in driver v1.1 only | V168 | Obj\NoYes |

Thermostat

Object Type: [HeatmiserNeo v11/Thermostat]

Object Type: [HeatmiserNeo v10/Thermostat]

A thermostat object contains values for a programmable room thermostat. Typically a neoStat in thermostat mode.

The neoStat's Current Setpoint (V9) object holds the current setpoint in use for the current mode. For example, if the mode changes to 'standby', then the frost protect setpoint is copied into the current setpoint. This setpoint can be temporarily overridden if required.

To integrate with another HVAC system, you may need the setpoint when the neoStat is in heating mode, and not standby. The driver adds this function with the Manual Setpoint (SP) object – providing either the current setpoint, or the last setpoint before the mode changed to standby, hold, away, or holiday.

| Description | Reference | Type |
|--|-----------|------------------------------|
| Label Zone label | L | Obj\Text: max 30; Adjustable |
| Standby Mode Activates standby mode, also called frost protection mode. In this mode the neoStat will only turn on heating if the room temperature falls below the Frost Temperature | V46 | Obj\OffOn; Adjustable |
| Current Setpoint Current temperature setpoint in use for the current mode. This setpoint can be overridden until the next programmed comfort level, or change of mode | V9 | Obj\Num: 7...35; Adjustable |
| Manual Setpoint Adjustable Indicates that the Manual Setpoint is currently adjustable. This is only possible when the neoStat is not in standby, hold, away, or holiday mode | SPA | Obj\NoYes |
| Manual Setpoint Driver generated value containing the (heating) setpoint used when the neoStat is not in standby, hold, away, or holiday mode. When the interface is started, this value will not be available until Standby Mode is off. | SP | Obj\Num: 7...35; Adjustable |
| Room Temperature | V10 | Obj\Float |
| Floor Temperature | V8 | Obj\Num |
| Room Humidity (%) | V28 | Obj\Num |
| Maximum Temperature | V32 | Obj\Float |
| Minimum Temperature | V33 | Obj\Float |
| Frost Protection Setpoint Temperature maintained in standby or holiday modes | V109 | Obj\Num: 7...17; Adjustable |
| Heating Demand Indicates thermostat is calling for heat | V23 | Obj\OffOn |
| Hold Indicates if hold mode is active. The hold function manually overrides the current program for a period of time | V49 | Obj\OffOn |

| Description | Reference | Type |
|---|-----------|---|
| Hold Temperature Setpoint temperature when hold mode is active. Set to activate hold temperature for Default Hold Time, or '0' to cancel hold | V24 | Obj\Num; Adjustable |
| Hold Time Remaining (mins) The time remaining in hold mode, if active. Set a time to activate or extend the hold time, or '0' to cancel hold | V25 | Obj\Num; Adjustable |
| Away | V1 | Obj\NoYes; Adjustable |
| Holiday Indicates holiday mode is active. In this mode the neoStat will only turn on heating if the room temperature falls below the Frost Temperature | V26 | Obj\NoYes |
| Holiday Days Remaining The number of days remaining in holiday mode | V27 | Obj\Num |
| Floor Limit Indicates the floor has reached the floor limit temperature | V20 | Obj\NoYes |
| Floor Temperature Limit Set a floor limiting temperature, depending on sensor selection. | V108 | Obj\Num: 20...45; Adjustable |
| Next On Time | V35 | Obj\Text |
| Program Mode Program mode option for the neoStats Comfort Level and Timeclock profiles. In 'Non-programmable' mode no profile is available. In '24 Hour' programming all days use Monday for the same profile. In '5Day/2Day' programming use Monday for the weekday profile, and Sunday for the weekend profile. In '7 Day' programming each day of the week has a profile. | V41 | Obj\Text Values: NONPROGRAMMABLE, 24HOURSFIXED, 5DAY2DAY, 7DAY |
| Comfort Level – day Contains a list of time-temperature values to define the profile for a <i>day</i> . Refer to Program Mode for which days are in use. A profile contains up to four time-temperature values, referred within Heatmiser at wake, leave, return, sleep. The day, <i>y</i> , is in the range 1...7 where 1=Monday .. 7=Sunday | Py | Obj\Profile: 4 periods; Adjustable |
| Enable Boiler | V13 | Obj\NoYes |
| Enable Pump | V15 | Obj\NoYes |
| Enable Valve | V16 | Obj\NoYes |
| Enable Zone | V17 | Obj\NoYes |
| Fail-safe State | V18 | Obj\OffOn; Adjustable |
| Fail-safe Enabled | V19 | Obj\NoYes |
| Output Delay | V37 | Obj\OffOn |
| Output Delay (mins) To prevent rapid switching, an output delay set | V111 | Obj\Num: 0...15; Adjustable |
| Switching Delay | V117 | Obj\Num; Adjustable |
| Switching Delay Time Remaining | V118 | Obj\Text |

| Description | Reference | Type |
|--|-----------|--|
| Switching Differential Controls the switching differential of the thermostat. The default is 1°, which means with a setpoint temperature of 20°, the thermostat will switch the heating on at 19° and off at 20° | V116 | Obj\Enum: 0..3; Adjustable Values: 0=0.5°, 1=1°, 2=2°, 3=3° |
| User Up/Down Limit Limits the use of the up/down temperature keys | V121 | Obj\Num: 0...10; Adjustable |
| Preheat Indicates optimum start is active | V39 | Obj\OffOn |
| Preheat Time | V40 | Obj\Text |
| Max Preheat (Hrs) Optimum start will delay the start up of the heating system to the latest possible moment. | V110 | Obj\Num: 0...5; Adjustable |
| Rate of Change (mins) Used for optimum start. Number of minutes for 1°C temperature rise | V115 | Obj\Num |
| Pump Delay | V42 | Obj\OffOn |
| Pump Delay Setting | V112 | Obj\Num: 0...20; Adjustable |
| Pump Delay Time Remaining | V113 | Obj\Text |
| Lock Indicates if the keypad lock is active. Set to 'Off' (0) to unlock the keypad | V29 | Obj\OffOn; Adjustable |
| Lock PIN Set a 4-digit PIN to activate the keypad lock | V30 | Obj\Text: max 4 chars; Adjustable |
| Low Battery | V31 | Obj\NoYes |
| Offline | V36 | Obj\NoYes |
| Sensor Selection | V44 | Obj\Text Values: BUILT_IN_AIR_SENSOR, REMOTE_AIR_SENSOR, FLOOR_SENSOR_ONLY, BUILT_IN_AND_FLOOR, REMOTE_SENSOR_AND_FLOOR |
| Heat Source | V43 | Obj\Enum Value: 0=Radiator, 1=Underfloor |
| Device Type | V12 | Obj\Enum Values: 1=neoStat, 6=neoPlug, 7=neoAir, 10=Repeater, 12=neoStat v2 |
| Device Mode Indicates if the device is in thermostat or time clock mode | V47 | Obj\Enum Values: 1=Timeclock, 2=Thermostat |
| Version Number | V53 | Obj\Num |
| Version Ultra Available in driver v1.1 only | V61 | Obj\Num |
| Write Count | V54 | Obj\Num |

Time Clock

Object Type: [HeatmiserNeo v11/Timeclock]

Object Type: [HeatmiserNeo v10/Timeclock]

A timeclock object contains values for a programmable time clock. Typically a neoStat-hw in time clock mode.

| Description | Reference | Type |
|--|-----------|---|
| Label Zone label | L | Obj\Text: max 30; Adjustable |
| Timer State | V51 | Obj\OffOn |
| Standby Activates standby mode | V46 | Obj\OffOn; Adjustable |
| Timer Boost Indicates if boost mode is active. The boost function manually overrides the current program for a period of time. Set 'on' to activate boost for Default Hold Time, or 'no' to cancel | V49 | Obj\OffOn; Adjustable |
| Timer Boost Time (mins) The time remaining in boost mode, if active. Set a time to activate or extend the boost time, or '0' to cancel boost. | V25 | Obj\Num; Adjustable |
| Away | V1 | Obj\NoYes; Adjustable |
| Holiday Indicates holiday mode is active. In this mode the neoStat will only turn on heating if the room temperature falls below the Frost Temperature | V26 | Obj\NoYes |
| Holiday Days Remaining The number of days remaining in holiday mode | V27 | Obj\Num |
| Next On Time | V35 | Obj\Text |
| Program Mode Program mode option for the neoStats Comfort Level and Timeclock profiles. In 'Non-programmable' mode no profile is available. In '24 Hour' programming all days use Monday for the same profile. In '5Day/2Day' programming use Monday for the weekday profile, and Sunday for the weekend profile. In '7 Day' programming each day of the week has a profile. | V41 | Obj\Text Values: NONPROGRAMMABLE, 24HOURSFIXED, 5DAY2DAY, 7DAY |
| Timeclock – day Contains a list of on-off times to define the profile for a <i>day</i> . Refer to Program Mode for which days are in use. A profile contains up to four on-off times, referred within Heatmiser at wake, leave, return, sleep. The day, <i>y</i> , is in the range 1...7 where 1=Monday .. 7=Sunday | Ty | Obj\Times: 4 periods; Adjustable |
| Fail-safe State | V18 | Obj\OffOn; Adjustable |
| Fail-safe Enabled | V19 | Obj\NoYes |

| Description | Reference | Type |
|--|-----------|--|
| Lock Indicates if the keypad lock is active. Set to 'Off' (0) to unlock the keypad | V29 | Obj\OffOn; Adjustable |
| Lock PIN Set a 4-digit PIN to activate the keypad lock | V30 | Obj\Text: max 4 chars; Adjustable |
| Low Battery | V31 | Obj\NoYes |
| Offline | V36 | Obj\NoYes |
| Device Type | V12 | Obj\Enum Values: 1=neoStat, 6=neoPlug, 7=neoAir, 10=Repeater, 12=neoStat v2 |
| Device Mode Indicates if the device is in thermostat or time clock mode | V47 | Obj\Enum Values: 1=Timeclock, 2=Thermostat |
| Version Number | V53 | Obj\Num |
| Version Ultra Available in driver v1.1 only | V61 | Obj\Num |
| Write Count | V54 | Obj\Num |

neoPlug

Object Type: [HeatmiserNeo v11/Switch]

Object Type: [HeatmiserNeo v10/Switch]

A neoPlug object contains values for a neoPlug switchable power socket.

| Description | Reference | Type |
|---|-----------|--|
| Label Zone label | L | Obj\Text: max 30; Adjustable |
| Output State | V51 | Obj\OffOn; Adjustable |
| Auto Program | V58 | Obj\OffOn; Adjustable |
| Hold Indicates if hold mode is active. The hold function manually overrides the current program for a period of time. | V49 | Obj\OffOn; Adjustable |
| Hold Time (mins) The time remaining in hold mode, if active | V25 | Obj\Num; Adjustable |
| Holiday Indicates holiday mode is active. In this mode the neoStat will only turn on heating if the room temperature falls below the Frost Temperature | V26 | Obj\NoYes |
| Holiday Days Remaining The number of days remaining in holiday mode | V27 | Obj\Num |
| Program Mode Program mode option for the neoStats Comfort Level and Timeclock profiles. In 'Non-programmable' mode no profile is available. In '24 Hour' programming all days use Monday for the same profile. In '5Day/2Day' programming use Monday for the weekday profile, and Sunday for the weekend profile. In '7 Day' programming each day of the week has a profile. | V41 | Obj\Text Values: NONPROGRAMMABLE, 24HOURSFIXED, 5DAY2DAY, 7DAY |
| Timeclock – day Contains a list of on-off times to define the profile for a <i>day</i> . Refer to Program Mode for which days are in use. A profile contains up to four on-off times, referred within Heatmiser at wake, leave, return, sleep. The day, <i>y</i> , is in the range 1...7 where 1=Monday .. 7=Sunday | Ty | Obj\Times: 4 periods; Adjustable |
| Fail-safe State | V18 | Obj\OffOn; Adjustable |
| Fail-safe Enabled | V19 | Obj\NoYes |
| Offline | V36 | Obj\NoYes |
| Low Battery | V31 | Obj\NoYes |
| Device Type | V12 | Obj\Enum Values: 1=neoStat, 6=neoPlug, 7=neoAir, 10=Repeater, 12=neoStat v2 |
| Version Number | V53 | Obj\Num |
| Version Ultra Available in driver v1.1 only | V61 | Obj\Num |
| Write Count | V54 | Obj\Num |

All Zones

Object Type: [HeatmiserNeo v11/AllZone]

Object Type: [HeatmiserNeo v10/AllZone]

The All Zones object is used to set common values across all zone devices.

| Description | Reference | Type |
|--|-----------|--|
| Standby Mode Activates frost protection mode. In this mode the neoStat will only turn on heating if the room temperature falls below the Frost Temperature | V46 | Obj\OffOn; Adjustable |
| Current Setpoint Adjust the setpoint temperature until the next programmed comfort level | V9 | Obj\Num: 7...35; Adjustable |
| Frost Protection Temperature Temperature maintained in standby or holiday modes | V109 | Obj\Num: 7...17; Adjustable |
| Away | V1 | Obj\NoYes; Adjustable |
| Floor Temperature Limit Set a floor limiting temperature, depending on sensor selection. | V108 | Obj\Num: 20...45; Adjustable |
| Fail-safe State | V18 | Obj\OffOn; Adjustable |
| Output Delay (mins) To prevent rapid switching, an output delay set | V111 | Obj\Num: 0...15; Adjustable |
| Switching Delay | V117 | Obj\Num; Adjustable |
| Switching Differential Controls the switching differential of the thermostat. The default is 1°, which means with a setpoint temperature of 20°, the thermostat will switch the heating on at 19° and off at 20° | V116 | Obj\ENum: 0..3; Adjustable Values: 0=0.5°, 1=1°, 2=2°, 3=3° |
| User Up/Down Limit Limits the use of the up/down temperature keys | V121 | Obj\Num: 0...10; Adjustable |
| Max Preheat (Hrs) Optimum start will delay the start up of the heating system to the latest possible moment. | V110 | Obj\Num: 0...5; Adjustable |
| Pump Delay Setting | V112 | Obj\Num: 0...20; Adjustable |
| Lock Indicates if the keypad lock is active. Set to 'Off' (0) to unlock the keypad | V29 | Obj\OffOn; Adjustable |
| Lock PIN Set a 4-digit PIN to activate the keypad lock | V30 | Obj\Text: max 4 chars; Adjustable |

All Thermostats

Object Type: [HeatmiserNeo v11/AllThermostat]

Object Type: [HeatmiserNeo v10/AllThermostat]

The All Thermostats object is used to set common values across all zone thermostat devices.

| Description | Reference | Type |
|---|-----------|--|
| Standby/Frost Protect Activates frost protection mode. In this mode the neoStat will only turn on heating if the room temperature falls below the Frost Temperature | V46 | Obj\OffOn; Adjustable |
| Current Setpoint Adjust the setpoint temperature until the next programmed comfort level | V9 | Obj\Num: 7...35; Adjustable |
| Frost Protection Temperature Temperature maintained in frost protect or holiday modes | V109 | Obj\Num: 7...17; Adjustable |
| Hold Temperature Set to activate hold temperature for Default Hold Time, or '0' to cancel hold | V24 | Obj\Num; Adjustable |
| Hold Time Remaining (mins) Set a time to activate or extend the hold time, or '0' to cancel hold | V25 | Obj\Num; Adjustable |
| Away | V1 | Obj\NoYes; Adjustable |
| Floor Temperature Limit Set a floor limiting temperature, depending on sensor selection. | V108 | Obj\Num: 20...45; Adjustable |
| Comfort Level – day Contains a list of time-temperature values to define the profile for a <i>day</i> . Refer to Program Mode for which days are in use. A profile contains up to four time-temperature values, referred within Heatmiser at wake, leave, return, sleep. The day, <i>y</i> , is in the range 1...7 where 1=Monday .. 7=Sunday | Py | Obj\Profile: 4 periods; Adjustable |
| Fail-safe State | V18 | Obj\OffOn; Adjustable |
| Output Delay (mins) To prevent rapid switching, an output delay set | V111 | Obj\Num: 0...15; Adjustable |
| Switching Delay | V117 | Obj\Num; Adjustable |
| Switching Differential Controls the switching differential of the thermostat. The default is 1°, which means with a setpoint temperature of 20°, the thermostat will switch the heating on at 19° and off at 20° | V116 | Obj\ENum: 0..3; Adjustable Values: 0=0.5°, 1=1°, 2=2°, 3=3° |
| User Up/Down Limit Limits the use of the up/down temperature keys | V121 | Obj\Num: 0...10; Adjustable |
| Max Preheat (Hrs) Optimum start will delay the start-up of the heating system to the latest possible moment. | V110 | Obj\Num: 0...5; Adjustable |
| Pump Delay Setting | V112 | Obj\Num: 0...20; Adjustable |

| Description | Reference | Type |
|--|-----------|-----------------------------------|
| Lock Indicates if the keypad lock is active. Set to 'Off' (0) to unlock the keypad | V29 | Obj\OffOn; Adjustable |
| Lock PIN Set a 4-digit PIN to activate the keypad lock | V30 | Obj\Text: max 4 chars; Adjustable |

All Time Clocks

Object Type: [HeatmiserNeo v11/AllTimeclock]

Object Type: [HeatmiserNeo v10/AllTimeclock]

The All Time Clocks object is used to set common values across all zone time clock devices.

| Description | Reference | Type |
|---|-----------|-----------------------------------|
| Standby Activates standby mode | V46 | Obj\OffOn; Adjustable |
| Timer Boost Indicates if boost mode is active. The boost function manually overrides the current program for a period of time. | V49 | Obj\OffOn; Adjustable |
| Timer Boost Time (min) The time remaining in boost mode, if active. Set a time to activate the boost function. | V25 | Obj\Num; Adjustable |
| Away | V1 | Obj\NoYes; Adjustable |
| Timeclock – day Contains a list of on-off times to define the profile for a <i>day</i> . Refer to Program Mode for which days are in use. A profile contains up to four on-off times, referred within Heatmiser at wake, leave, return, sleep. The day, <i>y</i> , is in the range 1...7 where 1=Monday .. 7=Sunday | Ty | Obj\Times: 4 periods; Adjustable |
| Fail-safe State | V18 | Obj\OffOn; Adjustable |
| Lock Indicates if the keypad lock is active. Set to 'Off' (0) to unlock the keypad | V29 | Obj\OffOn; Adjustable |
| Lock PIN Set a 4-digit PIN to activate the keypad lock | V30 | Obj\Text: max 4 chars; Adjustable |

Driver Versions

| Version | Build Date | Details |
|---------|------------|---|
| 1.0 | 1/08/2016 | Driver released |
| 1.1 | 26/05/2017 | <p>neoHub devices can be configured with an address > 32. Driver updated to allow for this.</p> <p>Added additional objects supported in neoHub firmware version 2058.</p> <p>Hold Temperature and Time Remaining are now adjustable for neoStats.</p> <p>Added driver object for Default Hold Time.</p> <p>Modified Hold Time Remaining and Timer Boost Time to use minutes, rather than 'h:mm' string.</p> <p>For comfort level profiles and timeclocks, now check program mode for zone rather than system.</p> <p>When writing value to zone, update value in driver cache. Reading value will then give new value, rather than waiting for driver cache to update.</p> |
| 1.1 | 01/09/2017 | <p>Added additional advanced setup objects to control how frequently the neoHub is polled for values</p> <p>Added Manual Setpoint object (SP) to provide standard heating setpoint when not in standby, hold, away or holiday modes.</p> <p>Improved response processing speed.</p> <p>Queue writes to neoHub, and check for COV before writing.</p> <p>When the Heatmiser system is experiencing problems on its wireless network, or too many write commands are sent, the neoHub can become slow to respond. The driver now waits longer for a response, and disconnects for a period of time if the neoHub becomes slow to respond.</p> <p>Added counters to indicate number of writes sent, and response time.</p> <p>Driver tested using a neoHub with firmware version 2066.</p> |
| 1.1 | 29/05/2018 | Added support for neoStat v2 |

Next Steps...

If you require help, contact support on 01273 694422 or visit www.northbt.com/support



North Building Technologies Ltd
 +44 (0) 1273 694422
 support@northbt.com
 www.northbt.com

This document is subject to change without notice and does not represent any commitment by North Building Technologies Ltd.

ObSys and Commander are trademarks of North Building Technologies Ltd. All other trademarks are property of their respective owners.

© Copyright 2018 North Building Technologies Limited.

Author: JF
 Checked by: BS

Document issued 12/06/2018.