


# Product Engineering Guide

## OSM v20 Meissner v10

---

### **Introduction**

The Meissner OSM links a Mega Systems Technologies UPS (called Meissner System in this document) to ObServer. The OSM can obtain a list of read only values from within the Meissner system, such as charge and battery statuses.



### **Notes**

No control over the Meissner system is possible as the OSM.

---

## **Engineering**

### **Step 1 – Install OSM**

The Meissner OSM is installed automatically with all ObSys editions. Refer to the 'ObSys CD sleeve' for details on how to install ObSys.

### **Step 2 – Plug in Meissner OSM to ObServer**

Use object engineering software to locate the ObServer Setup object. Assign the Meissner OSM to an available channel. Refer to 'ObServer v20 Application Engineering Guide'.

Note: After inserting the OSM, your engineering software may need to re-scan the ObServer object in order to view the OSM.

### **Step 3 – Configure Meissner Module**

The Device label and Alarm Object require engineering in the Module. Use object engineering software to view and modify the module objects within the OSM.

Note: After engineering the Module, your engineering software may need to re-scan the Meissner System in order to view the Meissner System.

### **Step 4 – Access Objects within the Meissner System**

Values from the Meissner system are made available as objects connected to ObServer. Any object software that is connected to ObServer can access these objects.

---

## Engineering Reference

### Cable Specification

The cable between COM port and the Meissner system 10-way Stocko connector is site specific.

### Objects

When the OSM is loaded the following objects are created within ObServer, use object software to access these objects.

Object <sup>[1]</sup>	Label	R/W	Type
Sc	Meissner System connected to channel <i>c</i>	-	[Meissner v10] <sup>[2]</sup>
Mc	Meissner Module connected to channel <i>c</i>	-	[OSM v20\Meissner v10]

### Notes

- [1] The ObServer channel number, *c*, is a number in the range 1...40.
- [2] This object has a variable content and as such requires scanning.